

JT2002
Auto Range Multimeter
User Manual

Table of Contents

Title	Page
Overview	4
Unpacking Inspection	5
Safety Information	6
Rules For Safe Operation	7
International Electrical Symbols	9
The Meter Structure	10
Rotary Switch	11
Functional Buttons	12
Display Symbols	13
Measurement Operation	15
A. DC/AC Voltage Measurement	15
B. DC/AC Current Measurement	18
C. Measuring Resistance	21
D. Testing for Continuity	24
E. Testing Diodes	26
F. Capacitance Measurement	29
G. Frequency Measurement	32
H. Temperature Measurement	34
Operation of Hold Mode	36
RANGE Button	36
MAX MIN Button	36

JT2002

Auto Range Multimeter User Manual



Title	Page
The Use of Relative Value Mode	37
The BLUE Button	37
Turning on the Display Backlight	38
Sleep Mode	38
General Specifications	39
Accuracy Specifications	40
A. DC Voltage	41
B. AC Voltage	42
C. DC Current	43
D. AC Current	44
E. Resistance	45
F. Capacitance	46
G. Frequency	47
H. Diode Test	48
I. Continuity Test	48
J. Temperature	49
Maintenance	50
A. General Service	50
B. Replacing the Battery	51
C. Replacing the Fuses	53

Overview

This Operating Manual covers information on safety and cautions. Please read the relevant information carefully and observe all the Warnings and Notes strictly.

Warning

To avoid electric shock or personal injury, read the “Safety Information” and “Rules for Safety Operation” carefully before using the Meter.”

Digital Multimeter (hereafter referred to as “the Meter”) is an auto ranging multimeter. The enclosure structure design adopted advanced “co-injection” technique in order to provide sufficient insulation.

The Meter can measure AC/DC Voltage and Current, Resistance, Diode, Continuity, Buzzer, Capacitance, Frequency, Temperature (°C or °F).

In addition to the conventional measuring functions, there is data hold, relative mode, peak measurement, low battery display, display backlight and sleep mode.

JT2002

Auto Range Multimeter User Manual



Unpacking Inspection

Open the package case and take out the Meter. Check the following item carefully to see any missing or damaged part:

Item	Description	Qty
1	Operating Manual	1 piece
2	Test Lead	1 pair
3	Point Contact K type Temperature Probe	1 piece
4	Multi-Purpose Socket	1 piece
5	9V Battery (NEDA1604, 6F22 or 0006P) (installed inside the Meter)	1 piece

In the event you find any of them missing or damaged, please contact your supplier immediately.

Safety Information

This Meter complies with the standards EN 61010-1, EN 61010-2-030: in pollution degree 2, overvoltage category (CAT III 1000V, CAT IV 600V) and double insulation.

CAT III: Distribution level, fixed installation, with smaller transient overvoltages than CAT IV.

CAT IV: Primary supply level, overhead lines, cable systems, etc.
Use the Meter only as specified in this operating manual, otherwise the protection provided by the Meter may be impaired.

In this manual, a Warning identifies conditions and actions that pose hazards to the user, or may damage the Meter or the equipment under test.

A Note identifies the information that user should pay attention on.
International electrical symbols used on the Meter and in this Operating Manual are explained on page 9.

Rules for safe operation

Warning

To avoid possible electric shock or personal injury, and to avoid possible damage to the Meter or to the equipment under test, adhere to the following rules:

- Before using the Meter inspect the case. Do not use the Meter if it is damaged or the case (or part of the case) is removed. Look for cracks or missing plastic. Pay attention to the insulation around the connectors.
- Inspect the test leads for damaged insulation or exposed metal. Check the test leads for continuity. Replace damaged test leads with identical model number or electrical specifications before using the Meter.
- Do not apply more than the rated voltage, as marked on the Meter, between the terminals or between any terminal and grounding.
- The rotary switch should be placed in the right position and no changeover of range shall be made when a measurement is conducted to prevent damage of the Meter.
- When the Meter is working at an effective voltage over 60V in DC or 30V rms in AC, special care should be taken for there is danger of electric shock.

JT2002

Auto Range Multimeter User Manual



- Do not use or store the Meter in an environment of high temperature, humidity, explosive, inflammable and strong magnetic field. The performance of the Meter may deteriorate after dampened.
- When using the test leads, keep your fingers behind the finger guards.
- Disconnect circuit power and discharge all high-voltage capacitors before testing resistance, continuity and diodes.
- Before measuring current, check the Meter's fuses and turn off the current to be tested before connecting the Meter to the circuit. After connecting the circuit reliably, turn the current to be tested on.
- Replace the battery as soon as the battery indicator  appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
- When servicing the Meter, use only replacement parts with the same model number or identical electrical specifications.
- The internal circuit of the Meter shall not be altered at will to avoid damage of the Meter and any accident.

JT2002

Auto Range Multimeter User Manual

- Soft cloth and mild detergent should be used to clean the surface of the Meter after servicing. No abrasive and solvent should be used to prevent the surface of the Meter from corrosion, damage and accident.
- The Meter is suitable for indoor use.
- Turn the Meter off when it is not in use and take out the battery when not using it for a long time.
- Constantly check the battery as it may leak when it has not been used for some time, replace the battery as soon as leaking appears. A leaking battery will damage the Meter.

International Electrical Symbols

	AC or DC		Grounding
	Double Insulated		Deficiency of Built-In Battery
	Warning. Refer to the Operating Manual		Conforms to Standards of European Union

The Meter Structure (see figure 1)

- 1 LCD Display
- 2 Functional Buttons
- 3 Blue button
- 4 Rotary Switch
- 5 Input Terminal




figure 1

Rotary Switch

Below table indicated for information about the rotary switch positions.

V_{\approx} mV \approx	AC and DC Voltage Measurement
Ω	Resistance Measurement
$\rightarrow +$	Diode Test
$\cdot)$	Continuity test
$\dashv $	Capacitance Test
Hz %	Frequency and Duty Cycle Test
$^{\circ}\text{C}$	Temperature in Celsius
$^{\circ}\text{F}$	Temperature in Fahrenheit
μA \approx	DCA and ACA Measurement
mA \approx	DCmA and ACmA Measurement
10A \approx	10A DC and AC Measurement
OFF	Power off

Functional Buttons

Below table indicated for information about the functional button operations.

Button	Operation Performed
LIGHT	Press and hold for 2 seconds to turn the display backlight on or off.
Hold	Press to enter or exit data hold mode.
BLUE Button	Press to select the alternate feature.
RANGE	<ul style="list-style-type: none">● Press RANGE to enter the manual ranging mode; the Meter beeps.● Press RANGE to step through the ranges available for the selected function; the Meter beeps.● Press and hold RANGE for 2 seconds to return to autoranging; the Meter beeps.
MAX/MIN	Press to select the maximum and minimum value.
REL Δ	<ul style="list-style-type: none">● Press to enter REL mode.● Press again to exit REL mode.

Display Symbols

N°	Symbol	Meaning
1		Data hold is active.
2		Sleep Mode indicator
3		Indicates negative reading.
4	AC	Indicator for AC measurement
5	DC	Indicator for DC measurement
6	AUTO	The Meter is in the auto range mode in which the Meter automatically selects the range with the best resolution.
7	MANU	Indicator for manual ranging mode.
8	OL	The input value is too large for the selected range.
9		Test of diode
10		The continuity buzzer is on.
11	MAX/MIN	Maximum and Minimum reading.
12		Data output is in progress
13		The battery is low. ⚠ Warning: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.

JT2002

Auto Range Multimeter User Manual



N°	Symbol	Meaning
16	Δ	The REL is on to display the stored value minus the present value.
17	Ω , k Ω , M Ω	Ω : Ohm. The unit of resistance.
		k Ω : kilohm. 1×10^3 or 1,000 ohms.
		M Ω : Megaohm. 1×10^6 or 1,000,000 ohms.
	mV, V	V: Volts. The unit of voltage.
		mV: Millivolt. 1×10^{-3} or 0.001 volts.
	μ A, mA, A	A: Amperes (amps). The unit of current.
		mA: Milliamp. 1×10^{-3} or 0.001 amperes
		μ A: Microamp. 1×10^{-6} or 0.000001 amperes
	nF, μ F, mF	F: Farad. The unit of capacitance.
		μ F: Microfarad. 1×10^{-6} or 0.000001 farads.
		nF: Nanofarad. 1×10^{-9} or 0.000000001 farads.
	$^{\circ}$ C, $^{\circ}$ F	$^{\circ}$ C: Centigrade. The unit of temperature.
		$^{\circ}$ F: Fahrenheit. The unit of temperature.
	Hz, kHz, MHz	Hz: Hertz. The unit of frequency in cycles/second.
		kHz: Kilohertz. 1×10^3 or 1,000 hertz.
MHz: Megahertz. 1×10^6 or 1,000,000 hertz.		

Measurement Operation

A. DC/AC Voltage Measurement (See figure 2)




figure 2

Warning

To avoid harms to you or damages to the Meter from electric shock, please do not attempt to measure voltages higher than 1000V although readings may be obtained.

When measuring high voltage, take extra care to avoid electric shock.

1. Insert the red test lead into the V terminal and the black test lead into the COM terminal.
2. Set the rotary switch to V; DC measurement is set by default or press BLUE button to switch between DC and AC measurement mode.
3. Connect the test leads across two points of the object being measured.
The measured value is shown on the display.
Display effective value of sine wave (mean value response).

- Input Amplitude: (DC electric level is zero).
- Input Amplitude: \geq range X30%
- Frequency response: \leq 1 kHz

Note

- In each range, the Meter has an input impedance of $10\text{M}\Omega$ except mV range, whose input impedance is $3000\text{M}\Omega$. This loading effect can cause measurement errors in high impedance circuits. If the circuit impedance is less than or equal to $10\text{k}\Omega$, the error is negligible (0.1% or less).
- When voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

B. DC/AC Current Measurement (See figure 3)




figure 3

Warning

Before connecting the Meter to the return circuit to be tested, cut off the current of the return circuit.

If the fuse burns out during measurement, the Meter may be damaged or the operator himself may be hurt.

Use proper terminals, function, and range for the measurement.

When the testing leads are connected to the current terminals, they should not be in parallel across the circuit.

To measure current, do the following:

1. Insert the red test lead into the mA or A input terminal and the black test lead into the COM terminal.
2. Set the rotary switch to μA , mA, or A.
3. The Meter defaults to DC current measurement mode. To toggle between DC and AC current measurement function, press BLUE button.
4. Connect the test lead in series to the return circuit to be tested. The measured value is shown on the display.
Display effective value of sine wave (mean value response).

5. Press Hz% to obtain the frequency and duty cycle value.

- Input Amplitude: (DC electric level is zero).
- Input Amplitude: \geq range X30%
- Frequency response: \leq 1 kHz

Note

- If the value of current to be measured is unknown, use the maximum measurement position, and reduce the range step by step until a satisfactory reading is obtained.
- For safety sake, each measurement time for $>5A$ current should be less than 10 seconds and the interval time between 2 measurements should be greater than 15 minutes.
- When current measurement has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

C. Measuring Resistance (See figure 4)




figure 4

Warning

To avoid damages to the Meter or to the devices under test, disconnect circuit power and discharge all the high-voltage capacitors before measuring resistance.

To avoid harm to yourself, do not input higher than DC 60V or AC 30V voltages.

To measure resistance, connect the Meter as follows:

1. Insert the red test lead into the mA or A input terminal and the black test lead into the COM terminal.
2. Set the rotary switch to Ω ; resistance measurement (Ω) is set by default or press BLUE button to select Ω measurement mode.
3. Connect the test leads across two points of the object being measured. If there is lead on the resistor or SMT resistor, it is more convenience to use the included multipurpose socket to carry out testing. The measured value shows on the display.

Note

- The test leads can add 0.2Ω to 0.5Ω of error to resistance measurement. To obtain precise readings in low-resistance measurement, short-circuit the input terminals beforehand, using the relative measurement function button REL to automatically subtract the value measured when the testing leads are shortcircuited from the reading.
- If Ω reading with shorted test leads is not $\leq 0.5\Omega$, check for loose test leads or other reasons.
- For high-resistance measurement ($>1\text{ M}\Omega$), it is normal to take several seconds to obtain a stable reading. To obtain stable reading, use a test lead as short as possible or use the included multi-purpose socket to carry out measurement.
- The LCD displays **OL** indicating open-circuit for the tested resistor or that the resistor value is higher than the maximum range of the Meter.
- When resistance measurement has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

D. Testing for Continuity (See figure 5)




figure 5

Warning

To avoid damages to the Meter or to the devices under test, disconnect circuit power and discharge all the high-voltage capacitors before testing for continuity.

To avoid harm to yourself, do not input higher than DC 60V or AC 30V voltages.

To test for continuity, connect the Meter as below:

1. Insert the red test lead into the Ω terminal and the black test lead into the COM terminal.
2. Set the rotary switch to  and press BLUE button to select measurement mode.
3. The buzzer sounds continuously if the resistor to be tested is $<10\Omega$.
The buzzer does not sound if the resistor to be tested is $>35\Omega$.

Note

- Open circuit voltage is around 0.45V
- When continuity testing has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

E. Testing Diodes (See figure 6)




figure 6

Warning

To avoid possible damage to the Meter and to the device under test, disconnect circuit power and discharge all high-voltage capacitors before testing diodes.

To avoid harm to yourself, do not input higher than DC 60V or AC 30V voltages.

1. Insert the red test lead into the Ω terminal and the black test lead into the COM terminal.
2. Set the rotary switch to  and press **BLUE** button to select  measurement mode.
3. For forward voltage drop readings on any semiconductor component, place the red test lead on the component's anode and place the black test lead on the component's cathode. The measured value shows on the display.

Note

- In a circuit, a good diode should still produce a forward voltage drop reading of 0.5V to 0.8V; however, the reverse voltage drop reading can vary depending on the resistance of other pathways between the probe tips.
- Connect the test leads to the proper terminals as said above to avoid an error on display. The LCD will display OL indicating diode being tested is open or polarity is reversed. The unit of diode is Volt (V), displaying the forward voltage drop readings.
- When diode testing has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

F. Capacitance Measurement (See figure 7)




figure 7

Warning

To avoid damage to the Meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the DC Voltage function to confirm that the capacitor is discharged.

To measure capacitance, connect the Meter as follows:

1. Insert the red test lead into the  terminal and the black test lead into the COM terminal.
2. Set the rotary switch to  and press BLUE button to select nF measurement mode.
 - At that time, the Meter will display a fixed value as below which is the Meter internal fixed distributed capacitance value. To ensure accuracy when measuring a small value of capacitance, the tested value must subtract this value, REL mode can help on that. Around 10nF
 - For more convenience, use the included multi-purpose socket for measuring capacitor with leads or SMT capacitor. Insert the capacitor to be tested into the corresponding "+" and "-" jack of the multi-purpose socket. This method is more stable and correct for small value of capacitance testing.
3. Connect the test leads across two points of the object being measured. The measured value shows on the display.

Note

- It takes a longer time when the tested capacitor is more than 100uF
- The LCD displays OL indicating the tested capacitor is shorted or it exceeds the maximum range.
- When capacitance measurement has been completed, disconnect all the connection between multi-purpose socket, capacitor and the Meter.

G. Frequency Measurement (See figure 8)




figure 8

Warning

To avoid personal harm, do not attempt to input higher than 30V rms tested frequency voltage

To measure frequency, connect the Meter as follows:

1. Insert the red test lead into the Hz terminal and the black test lead into the COM terminal.
2. Set the rotary switch to Hz%; frequency measurement (Hz) is set by default or press Hz % button to select Hz measurement mode.
3. Connect the test leads across two points of the object being measured. The measured value shows on the display.
4. If you need to measure duty cycle, press Hz % button to select % measurement mode.

Note

- Input Amplitude: (DC electric level is zero)
- When 10Hz ~ 10MHz: $200\text{mV} \leq a \leq 30\text{Vrms}$
- When frequency measurement has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

H. Temperature Measurement (See figure 9)




figure 9

Warning

To avoid harm to yourself, do not input higher than DC 60V or AC 30V voltages.

To measure temperature, connect the Meter as follows:

1. Set the rotary switch to °C °F.
2. Insert the temperature probe into the input terminal as shown on the figure 9.
3. Place the temperature probe to the object being measured.
After a few seconds, the measured value will be shown on the display.
4. Press BLUE button to toggle between °C and °F temperature.

Note

- To avoid measurement error especially low temperature measurement, the operating temperature must not exceed 18 ~ 28 °C.
- When temperature measurement has been completed, disconnect the connection between the temperature probe and the object being measured, and remove the temperature probe away from the input terminals of the Meter.

Operation of Hold Mode

Warning

To avoid possibility of electric shock, do not use Hold mode to determine if circuits are without power. The Hold mode will not capture unstable or noisy readings.

The Hold mode is applicable to all measurement functions.

- Press HOLD to enter Hold mode; the Meter beeps.
- Press HOLD again to exit Hold mode; the Meter beeps.
- In Hold mode,  is displayed.

RANGE button.

- Press RANGE to enter the manual ranging mode; the Meter beeps.
- Press RANGE to step through the ranges available for the selected function; the Meter beeps.
- Press and hold RANGE for over 2 seconds to return to autoranging; the Meter beeps.

MAX MIN button.

- Press MAX MIN to start recording of maximum and minimum values. Steps the display through high (MAX) and low (MIN) readings. The Meter enters manual ranging mode after pressing MAX MIN button.
- Press and hold MAX MIN for over 2 seconds to exit MAX MIN mode and return to the present measurement range.

The Use of Relative Value Mode

The REL mode applies to all measurement functions except frequency/duty cycle measurement. It subtracts a stored value from the present measurement value and displays the result.

For instance, if the stored value is 20.0V and the present measurement value is 22.0V, the reading would be 2.0V. If a new measurement value is equal to the stored value then it will display 0.0V.

To enter or exit REL mode:

- Press **REL**  to enter REL mode, and the present measurement range is locked and displays "0" as the stored value.
- Press **REL**  again to reset the stored value and exit REL mode.

The BLUE button

It uses for selecting the required measurement function when there is more than one function at one position of the rotary switch.

Turning on the Display Backlight

Warning

In order to avoid the hazard arising from mistaken readings in insufficient light or poor vision, please use Display Backlight function.

- Press and hold HOLD/LIGHT for over 2 seconds to turn the Display Backlight on.
- The display backlight will automatically off around after 10 seconds.

Sleep Mode

To preserve battery life, the Meter automatically turns off if you do not turn the rotary switch or press any button for around 15 minutes.

The Meter can be activated by turning the rotary switch or pressing any button.

To disable the Sleep Mode function, press BLUE button while turning on the Meter.

General Specifications

- Maximum Voltage between any Terminals and Grounding:
Refer to the different ranges input protection voltage.
-  Fused Protection for μ AmA Input Terminal: 600mA H 1000V ϕ 6.35 x 31.8mm.
-  Fused Protection for 10A Input Terminal: 10A H 1000V ϕ 10.3 x 38.1mm.
- Display
 - Maximum reading 6000 (frequency 9999), analogue bar graph 61 segments.
- Measurement Speed: Updates 2~3 times/second.
- Range: Auto or Manual
- Polarity Display: Auto
- Overload indication: Display **OL**
- Battery Deficiency: Display 

JT2002

Auto Range Multimeter User Manual



- Temperature:
 - Operating: 0°C to +40°C (32°F to +104°F)
 - Storage: -10°C to +50°C (14°F to +122°F)
- Relative Humidity:
 - ≤75% @ 0°C ~ 30°C bellow.
 - ≤50% @ 30°C ~ 40°C.
- Battery Type: One piece of 9V (NEDA 1604 or 6F22 or 006P)
Under the influence of radiated Radio-Frequency electromagnetic Field phenomenon, the captioned model have a measurement error, it will be back to normal when the interference is removed.
- Dimensions (HxWxL): 180x87x47mm.
- Weight: Approximate 370g (battery included).
- Safety/Compliances:
EN 61010-1. EN 61010-2-030 CAT III 1000V, CAT IV 6000V overvoltage and double insulation standard.
- Certifications: 

Accuracy Specifications

Accuracy \pm a% reading + b digits guarantee for 1 year.

Operating temperature 18°C~28°C.

Relative humidity <75%.

JT2002

Auto Range Multimeter User Manual



A. DC Voltage

Range	Resolution	Accuracy	Input Impedance	Fixed Value Input
60mV	0.01mV	$\pm (0.8\%+3)$	Around >3000M Ω	1000V dc/ac
600mV	0.1mV	$\pm (0.8\%+3)$		
6V	0.001V	$\pm (0.5\%+1)$	Around 10M Ω	
60V	0.01V			
600V	0.1V			
1000V	1V			

B. AC Voltage

Range	Resolution	Accuracy	Input Impedance	Fixed Value Input
		45 ~ 1kHz		
60mV	0.01mV	$\pm (1.2\%+5)$	Around >3000M Ω	1000V dc/ac
600mV	0.1mV			
6V	0.001V	$\pm (0.5\%+1)$	Around 10M Ω	
60V	0.01V			
600V	0.1V			
1000V	1V	$\pm (1.2\%+5)$		

- Displays effective value of sine wave. mV range is applicable from 5% of range to 100% of range.

C. DC Current

Range	Resolution	Accuracy	Overload Protection
600 μ A	0.1 μ A	(1.0%+3)	Fuse1: F600mA H 1000V, Φ 6.35 x 31.8mm
6000 μ A	1 μ A		
60mA	0.01mA		
600mA	0.1mA		
6A	0.001A	(1.2%+5)	Fuse2: F10A H 1000V, Φ 10.3 x 38.1mm
10A	0.01A		

Remarks:

- When $\leq 5A$: Continuous measurement is allowed.
- When $> 5A$: Continuous measurement of less than 10 seconds with an interval of at least 15 minutes between measurements.

D. AC Current

Range	Resolution	Accuracy	Overload Protection
		45 ~ 1kHz	
600 μ A	0.1 μ A	(1.2%+5)	Fuse1: F600mA H 1000V, Φ 6.35 x 31.8mm
6000 μ A	1 μ A		
60mA	0.01mA	(1.5%+5)	
600mA	0.1mA		
6A	0.001A	(2.0%+5)	Fuse2: F10A H 1000V, Φ 10.3 x 38.1mm
10A	0.01A		

Remarks:

- When $\leq 5A$: Continuous measurement is allowed.
- When $>5A$: Continuous measurement of less than 10 seconds with an interval of at least 15 minutes between measurements.
- Displays effective value of sine wave.

E. Resistance

Range	Resolution	Accuracy	Overload Protection
600 Ω	0.1 Ω	$\pm(1.2\%+2)$	1000V dc/ac
6k Ω	0.001k Ω	$\pm(1.0\%+2)$	
60k Ω	0.01k Ω		
600k Ω	0.1k Ω		
6M Ω	0.001M Ω	$\pm(1.2\%+2)$	
60M Ω	0.01M Ω	$\pm(1.5\%+2)$	

Remark:

- When measuring below 2k Ω , apply REL Δ to ensure measurement accuracy.

F. Capacitance

Range	Resolution	Accuracy	Overload Protection
40nF	0.01nF	$\pm(3.0\%+5)$	1000V dc/ac
400nF	0.1nF		
4 μ F	0.001 μ F		
40 μ F	0.01 μ F		
400 μ F	0.1 μ F	$\pm(4.0\%+5)$	
4000 μ F	1 μ F	unspecified	

Remark:

- There is around 10nF residual reading when the circuit is open.

G. Frequency

Range	Accuracy	Maximum Resolution	Overload Protection
10Hz ~ 10MHz	(0.1%+4)	0.01Hz	1000V dc/ac

- Input Amplitude: (DC electric level is zero)
 - When 10Hz ~ 10MHz: $200\text{mV} \leq a \leq 30\text{Vrms}$
 - When measuring on line frequency or duty cycle under AC Voltage and Current measurement mode, the input amplitude and frequency response must satisfy the following requirement:
Input amplitude \geq range x 30%
Frequency response: $\leq 1\text{ kHz}$

H. Diode Test

Resolution	Remarks	Overload Protection
0.001V	Open circuit voltage around 2.8V	1000V dc/ac

I. Continuity Test

Resolution	Overload Protection
0.1 Ω	1000V dc/ac

- Open circuit voltage is around 0.45V.
- Broken circuit resistance value is around $> 35\Omega$, the buzzer does not beep.
- Good circuit resistance value is $\leq 10\Omega$, the buzzer beeps continuously.

J. Temperature Measurement

Range	Resolution	Accuracy	Overload Protection
°C	1°C	(-40°C ~ -20°C): -(8%+5)	1000V dc/ac
		(>-20°C ~ 0°C): ±(1.2%+4)	
		(>0°C ~ 100°C): ±(1.2%+3)	
		(>100°C ~ 1000°C): ±(2.5%+2)	
°F	1°F	(-40°F ~ 4°F): -(8%+6)	
		(>4°F ~ 32°F): ±(1.2%+5)	
		(>32°F ~ 212°F): ±(1.2%+4)	
		(>212°F ~ 1832°F): ±(2.5%+3)	

- Thermocouple:

It is suitable to use K type thermocouple. The included point contact K type thermocouple can only be used on less than 230°C temperature measurement.

Maintenance

This section provides basic maintenance information including battery and fuse replacement instruction.

Warning

Do not attempt to repair or service your Meter unless you are qualified to do so and have the relevant calibration, performance test, and service information.

To avoid electrical shock or damage to the Meter, do not get water inside the case.

A. General Service

- Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.
- To clean the terminals with cotton bar with detergent, as dirt or moisture in the terminals can affect readings.
- Turn off the power of the Meter when it is not in use.
- Take out the battery when it has been used for a long time.
- Do not use or store the Meter in a place of humidity, high temperature, explosive, inflammable and strong magnetic field.

B. Replacing the Battery




figure 10

Warning

To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator "c" appears.

Make sure the test leads are disconnected from the circuit being tested before opening the case bottom.

To replace the battery: (see figure 10)

1. Turn the Meter power off and remove all connections from the terminals.
2. Remove the screw from the tilt stand and the battery compartment and separate the battery compartment and the tilt stand from the case bottom.
3. Remove the battery from the battery compartment.
4. Replace the battery with a new 9V battery.
5. Rejoin the tilt stand, battery compartment and case bottom, and reinstall the screw.

C. Replacing the Fuses




figure 11

Warning

To avoid electrical shock or arc blast, or personal injury or damage to the Meter, use specified fuses ONLY in accordance with the following procedure.

To test the fuse: (see figure 11)

To replace the battery: (see figure 10)

1. Turn the Meter power off and remove all connections from the terminals.
2. Remove the screw from the tilt stand and the battery compartment and separate the battery compartment and the tilt stand from the case bottom.
3. Remove the two screws from the case bottom, and separate the case top from the case bottom.
4. Remove the fuse by gently prying one end loose, then take out the fuse from its bracket.
5. Install ONLY replacement fuses with the identical type and specification as follows and make sure the fuse is fixed firmly in the bracket.
 - μA mA range: F1, 600mA H 1000V, Φ6.35x31.8mm
 - 10A range: F2, 10A H 1000V, Φ10.3x38.1mm
6. Rejoin the case bottom and case top, and reinstall the screw.
7. Rejoin the tilt stand, battery compartment and case bottom, and reinstall the screw.



COJALI S.L.

Avenida de la Industria N3 · 13610 · Campo de Criptana · Spain

National Tel: +34 926 589 670

International Tel: +34 926 589 671

www.cojali.com · www.jaltest.com